



the most experienced name
in high speed cameras

MEMRECAM HX-5

High Speed Camera System

The MEMRECAM HX series:
the world's most versatile family of
high speed camera systems!

MEMRECAM HX-5 FEATURES

CMOS Sensor: 2560 X 1920—
all Active Pixels

Bit Depth: 12/10/8-bit
(customer selectable)

Electronic Shutter:
OPEN to $<1\mu\text{sec}$

Variable Framing Profile:
Test using a variety of frame
rates, sequentially or in parallel.

Versatile Recording: Burst,
multi-trigger, restart-trigger and
image trigger.

A-EST Mode: High resolution
timing and sync system to
 < 73 nanoseconds.

Straddle Mode:
Inter-frame time for
PIV applications equals
182 nanoseconds.

Dual Segment Recording:
Simultaneously record to two
distinct memory segments at
two different imaging speeds.

Ultra-High Light Sensitivity

Ruggedized for Range Use



nac's MEMRECAM HX-5 offers an astounding 5 Mega Pixel resolution at up to 1,370 fps, Full HD resolution at up to 3,210 fps, 1 Mega Pixel resolution at up to 6,340 fps, and so much more! The HX-5 gives the user the best possible solutions: the highest resolutions available; the highest light sensitivity available; and ultra fast imaging.

The HX-5 is literally two cameras in one!

*When it comes to reliable, high-quality, high-speed camera systems,
make the proven choice with nac and you'll see the visible difference!*

MEMRECAM HX-5

High Speed Camera System



MEMRECAM HX-5 High Resolution Mode		
Max Res (pixels)	2560 X 1920	
Optical Format	35.20 mm	
fps @ Max Res	1,370	
	Mono	Color
ISO Rating	10,000	2,000

MEMRECAM HX-5 High Speed Mode		
Max Res (pixels)	1280 X 960	
Optical Format	35.20 mm	
fps @ Max Res	5,290	
	Mono	Color
ISO Rating	40,000	8,000

Memory Option	16GB, 32GB, 64GB
Maximum fps	900,000

Imaging Formats	Max fps @ Format
High Def: 16 X 9	
1920 X 1080	3,210
1280 X 720	7,030
Other Formats	
4 Mega Pixel	1,650
2 Mega Pixel	3,260
1 Mega Pixel	6,340
XGA (1024 X 768)	8,100
768 X 576	13,910
VGA (640 X 480)	19,460
512 X 512	22,280
512 X 384	29,560
320 X 320	51,110
320 X 240	72,740
320 X 192	89,860
320 X 96	169,730
320 X 48	305,520
320 X 24	509,200

* Note: Recording Time Depends on Memory Configuration, Resolution, Frame Rate and Image Bit Depth.
 Recording Time (seconds) = [(Memory Configuration X 1024 X 1,000,000) / (Resolution/Frame)] / (Frames/Second)
 Resolution/Frame (Bytes) = (Horizontal pixels X Vertical Pixels X Bit Depth/8)

nac Image Technology

MEMRECAM High Speed Camera Systems also Feature:

- Auto Exposure Control
- Adjustable Frame Rates
- Automatic Temperature Calibration
- Continuously Adjustable Resolution
- Ultra-Fast Gig-E Interface with DataLock
- Fast Download to USB 2.0 HDD
- Continuous Live Video Output
- Remote & Local Control—(no PC required)
- Memory Backup
- DRES—Dynamic Range Expansion Shutter
- Multiple Trigger Modes
- Memory Segmentation
- External Sync Recording
- IRIG-B Capture & Sync with Phase Shift
- Compact, Rugged Design - 5.5kg
110W x 140H x 333D(mm)

Visit our website at
www.nacinc.com

Please Note: Specifications described above are preliminary and subject to change.



Contact Us in the Americas:
 nac Image Technology
 193 Jefferson Ave, Suite 102
 Salem, MA 01970 U.S.A.
 Tel: (833) 600-0280
 E-mail: sales@nacinc.com

Contact Us in Europe:
 nac Deutschland GmbH
 Hedelfingerstr. 54-70
 70327 Stuttgart, Germany
 Tel: +49(0)711 2201 885
 E-mail: rwestphal@nacinc.de

Contact Us in Asia:
 nac Image Technology Inc.
 2-11-3 Kita-Aoama, Minato-ku
 Tokyo 107-0061 Japan
 Tel: +81 3 3796 7903
 Email: nacinternational@camnac.co.jp